



Royal Netherlands Air Force

# Barometric pressure equalization properties of passive noise filters used in custom communications earplugs.

SAFE Europe Hamburg 2023


Royal Netherlands Air Force  
Centre for Man in Aviation  
Yuval Steinman

08 July 2024



## Introduction

- Military aircrafts have become increasingly noisy (>100 dB)
  - Helmet noise attenuation is insufficient especially in low frequency
  - Aircrew use double hearing protection (helmet + ear plug)
    - Negatively effects speech intelligibility





## Communications ear plug (CEP) – foam tips


- Pros
  - Provides extra hearing protection
  - Improves speech intelligibility
- Cons
  - Proper insertion takes too long
  - Large variation in attenuation
  - Foam tips don't always fit (one size doesn't fit all)
  - Pressure and irritation in ear canal
  - Increase of discomfort during long duration flights
  - Falls out
  - Hygiene





## Communications ear plug – custom molded



- Pros
  - Better fitting – minimize discomfort
  - Small variations in attenuation
  - Soft and flexible
  - Fast and easy insert
  - Don't fall easily out of the ear
- Cons
  - Complaints over pressure build-up in middle ear cavity
  - Custom ear plug change every 3-4 years





## Communications Ear Plug – vented custom molded

- Minimal vent diameter – 0.3mm\*
- Pros
  - Same advantages as non-vented custom molded ear plugs
  - Equalize pressure differential middle ear and ambient aircraft pressure
- Cons
  - Less attenuation at low frequencies




Alpha 900      Alpha 900 + Foam Earplug      Alpha 900 + Foam CEP  
Alpha 900 + Custom CEP      Alpha 900 + Vented CEP

\*Altitude Chamber Validation of Capillary Venting for Custom Earplugs, Air Force Research Laboratory, 2005




# Communications Ear Plug – custom molded passive noise filter

- Pros
  - Improves attenuation
  - Different passive filters
  - Can be used for walk-around
- Venting canal is blocked by a passive filter – what is the effect on pressure equalization during rapid ascent, rapid descent and rapid decompression (RD)?





Passive noise filter





## Method

- Two passive CEP filters
- Hypobaric chamber
- Equipment
  - Two test cells
    - Mimic ear canal volume (small)
    - Ambient pressure
  - Silicone adapter for fitting the filters
  - Pressure sensors (15 PSI-AF-prime-mini)
  - Signal amplifier
  - Data acquisition unit - Dataq DI-155/HS - 5000Hz
- Procedure
  - Check for leaks in test cell
  - Ascent - 10,000 ft - 4000 ft/min
  - Descent -10,000 ft - 4000 ft/min
  - RD - 8000 to 25,000 ft in 3 sec
  - Each test repeated 3 times






## Results - rapid ascent and descent

In both filters the pressure in the test cell was able to follow the pressure in the hypobaric chamber.

Filter 1



Filter 2








## Results – RD filter 1


- No lag in trapped volume venting in the test cell when using filter 1 during RD test.





## Results – RD filter 2

- A lag in trapped volume venting in test cell when using filter 2 during RD.
  - Peak pressure difference between 115 mbar (86 mmHg) and 215 mbar (161 mmHg)
  - Pressure equalization after ~50 sec
- Sever pain, nausea and occasionally vertigo, in some cases otologic barotrauma.





## Conclusions

- No significant pressure differential was found in both filters during rapid ascent and descent (4000 ft/min).
- No significant pressure differential was found in filter 1 during RD
- A significant pressure differential was found in filter 2 during RD
  - Filter 2 was inadequate to equalize the air volume trapped behind the earplug.
  - Can have a significant physiological effect
- CEP passive attenuation filters need to be designed to allow free flow of air even during extreme pressure changes.



## Determination of pressure equalization properties foam ear plugs


- Different types of foam ear plugs used by aircrew
  - Exposed cell surface texture or coated
  - Different shapes
  - Different insertion depth





## Results + conclusion

- No significant pressure differential was found in the different foam ear plugs during rapid ascent, rapid descent (4000 ft/min) or RD.
- Foam ear plugs approved for flight in aircrafts with risk of RD





Contact: [y.steinman.01@mindef.nl](mailto:y.steinman.01@mindef.nl)